Supplemental Materials for the Article "TACSEI: Tactile Sensing, State Estimation and Embodied Intelligence of a Soft Hand"

Task Task level (adjusted description according to tasks) (multimodal) Hardware Hardware level description and (pre-defined, fixed) manipulation skill (text) Role description of VLMs Hardware level (pre-defined, fixed) (text) Knowledge level Common knowledge definition (pre-defined, fixed) (text)

Fig. 1 Hierarchical pyramid prompt architecture of the VLMs for the proposed soft hand.

Prompt 1.1

```
Role: "system"

Content:
{
"type": "text", "text":
For rotation task, the clockwise and counterclockwise are defined below:

1) All makers, labels and symbols on the object rotate towards the same direction with the object.

2) **Clockwise**: a marker on the object rotates from top to right, then bottom, then left.

3) **Counterclockwise**: a marker on the object rotates from top to left, then bottom, then right.
}
```

Prompt 1.2

```
Role: "system"

Content:
{

"type": "text", "text":

For swing task, the clockwise and counterclockwise are defined below:

1) Focusing on a reference part on the **upper body of object**,
2) **Clockwise**: The reference part moves from top to right of the view.
3) **Counterclockwise**: The reference part moves from top to left of the view.
}
```

Prompt 1.3

```
Role: "system"

Content:
{
    "type": "text", "text":
    There are two cases for the bottle cap operation:
        1) **Opening**: The bottle cap is **initially on the bottle**, and is **finally removed from the bottle**.
        2) **Closing**: The bottle cap is **initially not on the bottle**, and **finally added to bottle**.
}
```

Prompt 2.1

```
Role: "system"
Content:
{
"type": "text", "text":
You are the controller of a soft robotic gripper designed to manipulate objects. Based on the provided hardware description and control objectives, generate control signals and strategies for actuation and manipulation.
}
```

Prompt 2.2

```
Role: "system"

Content:
{
"type": "text", "text":
You are a video analyzer.
}
```

Prompt 3.1

```
Role: "user"
Content:
{
"type": "text", "text":
```

3.1.1 Gripper Design:

- The gripper is a humanoid right hand in a pre-grasp pose with three soft, silicone fingers:
 - a) Thumb (TH): Positioned on the right side of the palm.
 - b) First Finger (FF): Positioned on the left side of the palm.
 - c) Middle Finger (MF): Positioned below the FF, on the same side.
- The TH and FF are opposite each other, while the MF aligns directionally with the FF.
- Each finger has multiple air chambers that can be independently actuated using compressed air.
- Action Mechanism: Inflating the chambers with compressed air causes the fingers to bend inward, enabling them to grasp objects.

3.1.2 Sensing ability:

- Each finger has a 4x8 tactile sensor array on its surface towards the target object to detect contact forces when interacting with an object.
- Sensors embedded between the air chambers measure forces generated during inflation, providing real-time feedback on finger states.

3.1.3 Control strategies:

- Pressure Range: Air pressure values range from 0 to 0.64 bar.
- Gripping Threshold: Fingers typically close and grip an object when the air pressure reaches approximately 0.4 bar.
- Smooth Transitions: Avoid sharp changes in air pressure for stability and precise control.
- Force Modulation:
 - a) Adjusting real-time air pressure for each finger enables fine-grained control of the gripping force.
 - b) Higher air pressure results in greater force applied toward the object.
- Finger Control: Independent control of the Thumb (TH), First Finger (FF), and Middle Finger (MF) allows for precise manipulation.
- Common Operations:
 - a) Gripping (Grasping): Securely hold objects by inflating all active fingers to ~0.4 bar.
 - b) Rotating: Adjust coordinated signals for the TH and FF while keeping the MF inactive (pressure = 0 bar).
 - c) Swinging: Manipulate pressure across the fingers to tilt or swing the grasped object in a specific direction.
- Rotation Strategy:
 - a) Use TH and FF to rotate a cylindrical object.
 - b) Maintain a stable grip pressure, averaging 0.3 to 0.4 bar for both fingers.
 - c) Keep the MF inactive (0 bar).
 - d) Introduce a **0.5-cycle phase difference and an amplitude difference (0.15 ~ 0.25 bar) between the TH and FF signals**.
 - e) **Larger average pressure and amplitude in the TH** signal rotates the object **toward the TH**.
 - f) **Larger average pressure and amplitude in the FF** signal rotates the object **toward the FF**.
- Swinging Strategy:
 - a) Adjust pressure among the fingers to swing the object:
 - b) Toward **FF/MF**: Increase pressure on the **TH and MF**. Largely decrease pressure on the **FF**.
 - c) Toward **TH**: Increase pressure on the **FF**. Largely decrease pressure on the **TH and MF**.

Role: "user" Content: { "type": "text", "text":

}

Generate a signal sequence for each finger (Thumb - TH, First Finger - FF, and Middle Finger - MF) to gradually hold an object and then slowly release it.

4.1.1 Signal Arrays:

Save the air pressure values for each finger in separate arrays:

- a) sig_th for the Thumb.
- b) sig_ff for the First Finger.
- c) sig_mf for the Middle Finger.
- d) return only excutable Python code to generate the sequences, without useless strings.

4.1.2 Sequence Properties:

- a) Each sequence must contain exactly 200 data points.
- b) Air pressure values should remain within the range of 0 to 0.64 bar.

4.1.3 Expected Behavior:

- a) Gradually increase air pressure to securely hold the object.
- b) Maintain a stable grip at peak pressure (around 0.4 bar) for a short duration.
- c) Slowly decrease pressure to release the object.
- d) Smooth the control signal after generation.

```
Role: "user"
Content:
"type": "video", "video": $the path of an attached video$,
"type": "text", "text":
Find the swing object held by the person and select a reference part on the **upper body of the object**, then describe the
movement.
```

Prompt 4.3

```
Role: "user"
Content:
"type": "text", "text":
Based on the demonstration result, generate signal sequences for each finger—Thumb (TH), First Finger (FF), and Middle
Finger (MF)—to **swing** an object **clockwise or counterclockwise**.
4.4.1 Signal Arrays:
Save the air pressure values for each finger in separate arrays:
```

- - a) **sig_th for the Thumb**. b) **sig ff for the First Finger**.
 - c) **sig_mf for the Middle Finger**.
 - d) Return only executable Python code to generate the sequences, without useless strings.
- 4.4.2 Sequence Properties:
 - a) The length of signal sequence for each finger must be the 200.
 - b) Air pressure values should remain within the range of 0 to 0.64 bar.
 - c) Smooth the control signal after generation.
- 4.4.3 Considering the space relationship between the soft hand and object:
 - a) **To swing clockwise: Swing toward the First Finger (FF) **.
 - b) **To swing counterclockwise: Swing toward the Thumb (TH) **.
 - c) Using the **Swinging Strategy** in previous prompt in **Prompt 3.1** to achieve the swinging.
- 4.4.4 Expected Behavior:
 - a) Gradually increase air pressure for all fingers to grip the object.
 - b) Maintain the pose for a short duration.
 - c) Adjust air pressure to **swing the object clockwise or counterclockwise as the demonstration result **.
 - d) Maintain the pose until the end.

Prompt 4.4

```
Role: "user"
Content:
"type": "video", "video": $the path of an attached video$,
"type": "text", "text":
Find the rotating object and a reference symbol/letter/marker and describe them.
```

```
Role: "user"

Content:
{
    "type": "text", "text": $ insert the output from the Prompt 4.4 here$,

"type": "text", "text":
Focusing on the rotating object with the letter 'A' and considering the previous definition of the clockwise and counterclockwise. Tell me if the object is rotating **clockwise** or **counterclockwise**
}
```

```
Prompt 4.6
Role: "user"
Content:
"type": "text", "text":
Based on the demonstration result, generate signal sequences for each finger—Thumb (TH), First Finger (FF), and Middle
Finger (MF)—to **rotate** the object **clockwise or counterclockwise**.
4.7.1 Signal Arrays:
Save the air pressure values for each finger in separate arrays:
    a) **sig_th for the Thumb**.
    b) **sig ff for the First Finger**.
    c) **sig_mf for the Middle Finger**.
    d) return only executable Python code to generate the sequences, without useless strings.
4.7.2 Sequence Properties:
    a) The length of signal sequence for each finger must be the 500.
    b) Air pressure values should remain within the range of **0 to 0.64** bar.
    c) The signal sequences for related fingers must contain cyclic variations in air pressure.
    d) Each cycle must consist of 20 data points for smooth air pressure modulation.
```

- 4.7.3 Considering the space relationship between the soft hand and object:
 - a) **To rotate clockwise: Larger average pressure and amplitude in the FF**.
 - b) **To rotate counterclockwise: Larger average pressure and amplitude in the TH**.
 - c) Using the **Rotation Strategy** in previous prompt in **Prompt 3.1** to achieve the rotation.

4.7.4 Expected Behavior:

- a) Introduce cyclic variations in the air pressure of TH and FF to generate rotational torque, maintaining grip stability.
- b) Ensure that the force/torque applied by TH and FF is coordinated to rotate the object **clockwise or counterclockwise** as the demonstration result.

Prompt 4.7

```
Role: "user"
Content:
{
"type": "video", "video": $the path of an attached video$,
"type": "text", "text":
Find the bottle and bottle cap and describe them.
}
```

```
Role: "user"

Content:
{
    "type": "text", "text": $ insert the output from the Prompt 4.7 here$,

"type": "text", "text":

Considering the previous definition and the status of bottle cap. Tell me if the person is **opening or closing** the bottle cap and explain the reason.
}
```

Prompt 4.9

```
Role: "user"
Content:
{
"type": "text", "text":
```

Based on the demonstration result, generate signal sequences for each finger—Thumb (TH), First Finger (FF), and Middle Finger (MF)—to **rotate** a bottle cap for either **opening or closing**.

4.10.1 Signal Arrays:

Save the air pressure values for each finger in separate arrays:

- a) **sig_th for the Thumb**.
- b) **sig_ff for the First Finger**.
- c) **sig_mf for the Middle Finger**.
- d) return only executable Python code to generate the sequences, without useless strings.

4.10.2 Sequence Properties:

- a) The length of signal sequence for each finger must be the 500.
- b) Air pressure values should remain within the range of **0 to 0.64** bar.
- c) The signal sequences for related fingers must contain cyclic variations in air pressure.
- d) Each cycle must consist of 20 data points for smooth air pressure modulation.
- 4.10.3 Considering the space relationship between the soft hand and bottle cap:
 - a) **Open: Rotate toward the Thumb (TH) **.
 - b) **Close: Rotate toward the First Finger (FF) **.
 - c) Using the **Rotation Strategy** in previous prompt in **Prompt 3.1** to achieve the rotation.

4.10.4 Expected Behavior:

- a) Introduce cyclic variations in the air pressure of TH and FF to generate rotational torque, maintaining grip stability.
- b) Ensure that the force/torque applied by TH and FF is coordinated to rotate the object in the required direction **opening or closing** as the demonstration result.